


Adjustable Index Pointer - on lens

- Designed to manually place index to a chosen position
- Option to have a fixed button (0052) or removable button (0053)



Non-adjustable Index Pointer - on dial

- Factory set location
- Option 0051



Maximum Index Pointer - on lens

- Pointer moves with pressure gauge pointer
- Operator can move back to zero
- Option for fixed button (0059) or removable button (0060)